



Laser Printer Dark

XP3129 - A4

XP3128 - A3

STEP BY STEP

Step 1

Print your design on the plain side of Laser Printer Dark along with the Xpres Cut Plus registration marks. (Templates can be found at www.xprestechnical.co.uk) - Do Not Mirror Image

Step 2

Contour cut using the Xpres Cut Plus process - (The manual for this process is available to download from www.xprestechnical.co.uk) Film blade required (60gf - 80gf)

Step 3

Weed away any excess material, remove the transfer and position on the garment by hand

Step 4

Cover the transfer with a single silicone sheet and press for 20 seconds at 125°C

Step 5

To avoid the toner sticking to the silicone paper, rub the silicone paper with a piece of fabric

PRINT SETTINGS

PAPER MODE:	Heavy
IMAGE MODE:	Do Not Mirror Image
FEEDING:	Bypass (manual feeding)

SUITABLE FOR

- ▶ Cotton
- ▶ Polyester
- ▶ Polyester/Cotton

Uncoated garments only

TRANSFER SETTINGS

TIME	20 seconds
TEMPERATURE	125°C
PRESSURE	Medium
PEEL	Hot or Cold

CARE INFORMATION

- ▶ Up to 40°C
- ▶ **Do not** tumble dry
- ▶ Can be ironed inside out

PLEASE NOTE: A4 samples are available free of charge upon request. Xpres cannot be held responsible for any copier/printer breakages.

PLEASE NOTE: The sellers and manufacturers maximum obligation shall be to replace any product that has been proven to be defective. Neither the seller nor the manufacturer of Laser Printer Dark shall be liable for any injury direct or consequential, arising out of the use of, or inability to use this range. Laser Printer Dark has been tested using Kustom Kit garments, use on other garment brands can not be guaranteed and should be tested prior to purchasing this material.

Oakridge Park, Trent Lane
Castle Donington, Derby
DE74 2PY

Phone: 01332 855 085
Web: www.xpres.co.uk
E-mail: sales@xpres.co.uk
Support: www.xprestechnical.co.uk