



Classic + Universal - Textiles

XP3414 - A4R

XP3413 - A3



Class 1



STEP BY STEP

Step 1

Print your design on the plain side of Classic + Universal in mirror image

Step 2

Trim away any excess material

Step 3

Place transfer face down onto the garment and press for 10 - 15 seconds at 200°C

Step 4

Peel immediately ensuring the garment stays on the bottom plate until the paper has been removed

Step 5

Cover your design with a silicone sheet and re-press for 10 seconds at 200°C

Step 6

For a softer touch stretch the garment after pressing

PRINT SETTINGS

PAPER MODE:	Heavy
IMAGE MODE:	Mirror Image
FEEDING:	Bypass (manual feeding)

PLEASE NOTE: Classic + Universal can be used in both oil based and non oil based printers

SUITABLE FOR- White and pastel coloured garments only

- ▶ Cotton
- ▶ Polyester
- ▶ Polyester/Cotton Uncoated garments only
- ▶ Mousemats - Please turn over for printing instructions

TRANSFER SETTINGS

TIME	10 - 15 + 10 seconds
TEMPERATURE	200°C
PRESSURE	Heavy
PEEL	Immediately

CARE INFORMATION

- ▶ Up to 40°C
- ▶ **Do not** tumble dry
- ▶ Can be ironed inside out

PLEASE NOTE: A4 samples are available free of charge upon request. Xpres cannot be held responsible for any copier/printer breakages.

PLEASE NOTE: The sellers and manufacturers maximum obligation shall be to replace any product that has been proven to be defective. Neither the seller nor the manufacturer of Classic + Universal shall be liable for any injury direct or consequential, arising out of the use of, or inability to use this range. Classic + Universal has been tested using Kustom Kit garments, use on other garment brands can not be guaranteed and should be tested prior to purchasing this material.

Oakridge Park, Trent Lane
Castle Donington, Derby
DE74 2PY

Phone: 01332 855 085
Web: www.xpres.co.uk
E-mail: sales@xpres.co.uk
Support: www.xprestechnical.co.uk



Classic + Universal Mousemat

XP3414 - A4R

XP3413 - A3



Class 1



STEP BY STEP

Step 1

Print your design on the plain side of Classic + Universal in mirror image, your design should be larger than the mousemat

Step 2

Trim away any excess material

Step 3

Secure your design to the mouse mat with heat tape and press for 3 seconds at 200°C

Step 4

Peel immediately ensuring the mouse mat stays on the bottom plate until the paper has been removed

PRINT SETTINGS

PAPER MODE:	Heavy
IMAGE MODE:	Mirror Image
FEEDING:	Bypass (manual feeding)

PLEASE NOTE: Classic + Universal can be used in both oil based and non oil based printers

TRANSFER SETTINGS

TIME	3 seconds
TEMPERATURE	200°C
PRESSURE	Medium
PEEL	Immediately

PLEASE NOTE: The sellers and manufacturers maximum obligation shall be to replace any product that has been proven to be defective. Neither the seller nor the manufacturer of Classic + Universal shall be liable for any injury direct or consequential, arising out of the use of, or inability to use this range. Classic + Universal has been tested using Kustom Kit garments, use on other garment brands can not be guaranteed and should be tested prior to purchasing this material.

Oakridge Park, Trent Lane
Castle Donington, Derby
DE74 2PY

Phone: 01332 855 085
Web: www.xpres.co.uk
E-mail: sales@xpres.co.uk
Support: www.xprestechical.co.uk